



Hot Dog Roller

\$20 cleanup fee will be charged to any machine not returned in same condition received.

ELECTRICAL REQUIREMENTS: 15amp, 110v outlet

HOW TO OPERATE:

1. Preheat unit for 10 minutes to allow the grill surface to heat up.
2. Place hot dogs between rollers, up to 36 can fit, depending on the size.
3. Cook until they achieve a minimum internal temperature of 63 degrees, roughly 15 minutes.
4. Once cooked, hot dogs can be served immediately, or remain on the grill for up to 2 hours.

CLEANING:

- Wet a cloth with hot water and light soap mixture
- With the machine still on, hold the cloth on each roller, moving in from one end to other, until clean. (Do not touch roller with bare hand, rollers are very hot)
- Be sure to wipe down tray under rollers once complete

WARNING: DO NOT TOUCH rollers when unit is on, as they are extremely hot, and may cause serious injury.

If you have any questions regarding the operation of this machine, please call 740-322-6355 during normal business hours. Have a great event!

MAIN EVENTS PARTY RENTAL WILL NOT ASSUME ANY LIABILITY FOR INJURY DUE TO CARELESS HANDLING OR OPERATION OF THIS EQUIPMENT.